



**Flexsil-Lid Australia Pty Ltd**  
A.B.N. 98 145 987 828

55 Alicante St  
Minchinbury NSW 2770

Tel: +61 2 47 22 33 93  
Fax: +61 2 47 21 39 19  
Mobile: +61 4 16 117 216  
Email: [albert@flexsil-lid.com](mailto:albert@flexsil-lid.com)  
[www.flexsil-lid.com](http://www.flexsil-lid.com)

## Care and use instructions

- Wash before initial use
- Initial use maximum 180c, 356f
- Do not place item on direct heat or flame
- Please keep lid distance minimum of 150 mm (6 inches) from heat source e.g flame, element
- After removing lid from heat allow to cool down
- Do not pierce with sharp instrument
- Do not overstretch to non suitable pans and containers
- Do not stretch while warm
- Always use gloves when handling hot product
- Do not use scourers or harsh abrasives
- Do not use in heat above 220c, 428f
- For maximum performance ensure pan & lid dry
- Use caution when removing lid from hot pan



**2011 Gulfood Award Winner for:**

**‘Best new catering equipment innovation’**

**‘Best Innovation in the Gulfood Awards 2011’**